

Xena2889 Test Report

Test Summary

Test company: Xena Networks
Customer: Xena Networks
Test Date and Time: 2016-08-02, 03:00
Test Duration: 01:48:20 (h:m:s)

Generated By: Xena2889 v1.17, running on 'Microsoft Windows 7 Enterprise'

Test Setup

Test Configuration

Subtest Selection

Rate Test: Full Mesh Enabled
- Throughput Enabled
- Forwarding Enabled

Disabled Rate Test: Part.Mesh, 1:N Disabled Rate Test: Part.Mesh, N->N Congestion Control: Disabled Forward Pressure: Disabled Maximum Forwarding Rate: Disabled Address Caching Capacity: Disabled Address Learning Rate: Disabled Errored Frames Filtering: Disabled Broadcast Forwarding: Disabled

Test Options

Packet Sizes Used: 64,128,256,512,1024,1280,1518

Rate Type: Fraction
Fraction per Port: 100,00%

Latency Measurement Mode: Last-To-Last

Toggle Port Sync States: Yes

Traffic Configuration

Used Chassis

Chassis ID	Chassis Name	Address
C-0	New chassis	140.181.139.228:22606

Used Ports

Port ID	Interface Type	Speed	IP Address & Gateway	Protocol Segment Profile
P-0-2-1	SFP-O LR 1310 nm	AUTO	No address specified	1: Ethernet
P-0-2-2	SFP-O LR 1310 nm	AUTO	No address specified	1: Ethernet
P-0-2-3	SFP-O LR 1310 nm	AUTO	No address specified	1: Ethernet
P-0-2-4	SFP-O LR 1310 nm	AUTO	No address specified	1: Ethernet
P-0-2-5	SFP-O LR 1310 nm	AUTO	No address specified	1: Ethernet



Rate Test: Full Mesh Results

Test Setup

Duration: 30 seconds

Iteration: 1

Topology: Mesh
Direction: Bidirectional

Throughput Options

Initial Rate: 10,00%
Maximum Rate: 100,00%
Minimum Rate: 10,00%
Resolution: 0,50%

Used Ports

Port ID	
P-0-2-2	
P-0-2-1	
P-0-2-4	
P-0-2-5	
P-0-2-3	

Throughput Test Results


Frame Size	64	128	256	512	1024	1280
Result State	PASS	PASS	PASS	PASS	PASS	PASS
Iter. #	1	1	1	1	1	1
Tx Rate (Percent)	42,695 %	97,363 %	98,242 %	98,945 %	99,473 %	99,648 %
Tx Rate (L1) (Bit/s)	2,13 G	4,87 G	4,91 G	4,95 G	4,97 G	4,98 G
Tx Rate (Fps)	3.176.734	4.111.625	2.224.687	1.162.421	595.502	479.079
Rx Rate (Percent)	42,7 %	97,36 %	98,24 %	98,95 %	99,47 %	99,65 %
Rx Rate (L1) (Bit/s)	2,13 G	4,87 G	4,91 G	4,95 G	4,97 G	4,98 G
Rx Rate (Fps)	3,18 M	4,11 M	2,22 M	1,16 M	595,5 K	479,08 K
Loss Rate (Percent)	0 %	0 %	0 %	0 %	0 %	0 %
Loss (Frames)	0	0	0	0	0	0
P-0-2-1						
- Tx (Frames)	19.060.404	24.669.748	13.348.120	6.974.528	3.573.012	2.874.472
- Tx Rate (L1) (Bit/s)	426,95 M	973,63 M	982,42 M	989,45 M	994,73 M	996,48 M
- Tx Rate (Fps)	635.347	822.325	444.937	232.484	119.100	95.816
- Rx (Frames)	19.060.404	24.669.748	13.348.120	6.974.528	3.573.012	2.874.472
- Rx Rate (L1) (Bit/s)	426,95 M	973,63 M	982,42 M	989,45 M	994,73 M	996,48 M
- Rx Rate (Fps)	635.347	822.325	444.937	232.484	119.100	95.816
- Flood Count (Frames)	94	90	87	92	93	92
P-0-2-2						
- Tx (Frames)	19.060.404	24.669.748	13.348.120	6.974.528	3.573.012	2.874.472
- Tx Rate (L1) (Bit/s)	426,95 M	973,63 M	982,42 M	989,45 M	994,73 M	996,48 M
- Tx Rate (Fps)	635.347	822.325	444.937	232.484	119.100	95.816
- Rx (Frames)	19.060.404	24.669.748	13.348.120	6.974.528	3.573.012	2.874.472
- Rx Rate (L1) (Bit/s)	426,95 M	973,63 M	982,42 M	989,45 M	994,73 M	996,48 M
- Rx Rate (Fps)	635.347	822.325	444.937	232.484	119.100	95.816
- Flood Count (Frames)	94	93	93	93	95	93
P-0-2-3						
- Tx (Frames)	19.060.404	24.669.748	13.348.120	6.974.528	3.573.012	2.874.472
- Tx Rate (L1) (Bit/s)	426,95 M	973,63 M	982,42 M	989,45 M	994,73 M	996,48 M
- Tx Rate (Fps)	635.347	822.325	444.937	232.484	119.100	95.816
- Rx (Frames)	19.060.404	24.669.748	13.348.120	6.974.528	3.573.012	2.874.472
- Rx Rate (L1) (Bit/s)	426,95 M	973,63 M	982,42 M	989,45 M	994,73 M	996,48 M
- Rx Rate (Fps)	635.347	822.325	444.937	232.484	119.100	95.816
- Flood Count (Frames)	89	95	90	92	94	92
P-0-2-4						
- Tx (Frames)	19.060.404	24.669.748	13.348.120	6.974.528	3.573.012	2.874.472
- Tx Rate (L1) (Bit/s)	426,95 M	973,63 M	982,42 M	989,45 M	994,73 M	996,48 M
- Tx Rate (Fps)	635.347	822.325	444.937	232.484	119.100	95.816



- Rx (Frames)	19.060.404	24.669.748	13.348.120	6.974.528	3.573.012	2.874.472
- Rx Rate (L1) (Bit/s)	426,95 M	973,63 M	982,42 M	989,45 M	994,73 M	996,48 M
- Rx Rate (Fps)	635.347	822.325	444.937	232.484	119.100	95.816
- Flood Count (Frames)	90	91	88	91	93	89
P-0-2-5						
- Tx (Frames)	19.060.404	24.669.748	13.348.120	6.974.528	3.573.012	2.874.472
- Tx Rate (L1) (Bit/s)	426,95 M	973,63 M	982,42 M	989,45 M	994,73 M	996,48 M
- Tx Rate (Fps)	635.347	822.325	444.937	232.484	119.100	95.816
- Rx (Frames)	19.060.404	24.669.748	13.348.120	6.974.528	3.573.012	2.874.472
- Rx Rate (L1) (Bit/s)	426,95 M	973,63 M	982,42 M	989,45 M	994,73 M	996,48 M
- Rx Rate (Fps)	635.347	822.325	444.937	232.484	119.100	95.816
- Flood Count (Frames)	96	88	90	91	92	91

Frame Size	1518
Result State	PASS
Iter. #	1
Tx Rate (Percent)	99,648 %
Tx Rate (L1) (Bit/s)	4,98 G
Tx Rate (Fps)	404.943
Rx Rate (Percent)	99,65 %
Rx Rate (L1) (Bit/s)	4,98 G
Rx Rate (Fps)	404,94 K
Loss Rate (Percent)	0 %
Loss (Frames)	0
P-0-2-1	
- Tx (Frames)	2.429.656
- Tx Rate (L1) (Bit/s)	996,48 M
- Tx Rate (Fps)	80.989
- Rx (Frames)	2.429.656
- Rx Rate (L1) (Bit/s)	996,48 M
- Rx Rate (Fps)	80.989
- Flood Count (Frames)	88
P-0-2-2	
- Tx (Frames)	2.429.656
- Tx Rate (L1) (Bit/s)	996,48 M
- Tx Rate (Fps)	80.989
- Rx (Frames)	2.429.656
- Rx Rate (L1) (Bit/s)	996,48 M
- Rx Rate (Fps)	80.989
- Flood Count (Frames)	90
P-0-2-3	
- Tx (Frames)	2.429.656
- Tx Rate (L1) (Bit/s)	996,48 M
- Tx Rate (Fps)	80.989
- Rx (Frames)	2.429.656
- Rx Rate (L1) (Bit/s)	996,48 M
- Rx Rate (Fps)	80.989
- Flood Count (Frames)	92
P-0-2-4	
- Tx (Frames)	2.429.656
- Tx Rate (L1) (Bit/s)	996,48 M
- Tx Rate (Fps)	80.989
- Rx (Frames)	2.429.656
- Rx Rate (L1) (Bit/s)	996,48 M
- Rx Rate (Fps)	80.989
- Flood Count (Frames)	91
P-0-2-5	31
- Tx (Frames)	2.429.656
- Tx (Frames)	996,48 M
	•
- Tx Rate (Fps)	80.989
- Rx (Frames)	2.429.656
- Rx Rate (L1) (Bit/s)	996,48 M
- Rx Rate (Fps)	80.989
- Flood Count (Frames)	91





Forwarding Test Results

Results for 10,00% Rate


Frame Size	64	128	256	512	1024	1280
Result State	PASS	PASS	PASS	PASS	PASS	PASS
Iter. #	1	1	1	1	1	1
Tx Rate (Percent)	10 %	10 %	10 %	10 %	10 %	10 %
Tx Rate (L1) (Bit/s)	500 M	500 M	500 M	500 M	500 M	500 M
Tx Rate (Fps)	744.047	422.297	226.449	117.481	59.865	48.077
Rx Rate (Percent)	10 %	10 %	10 %	10 %	10 %	10 %
Rx Rate (L1) (Bit/s)	500 M	500 M	500 M	500 M	500 M	500 M
Rx Rate (Fps)	744,05 K	422,3 K	226,45 K	117,48 K	59,87 K	48,08 K
Loss Rate (Percent)	0 %	0 %	0 %	0 %	0 %	0 %
Loss (Frames)	0	0	0	0	0	0
P-0-2-1						
- Tx (Frames)	4.464.284	2.533.780	1.358.692	704.884	359.192	288.460
- Tx Rate (L1) (Bit/s)	100 M	100 M	100 M	100 M	100 M	100 M
- Tx Rate (Fps)	148.809	84.459	45.290	23.496	11.973	9.615
- Rx (Frames)	4.464.284	2.533.780	1.358.692	704.884	359.192	288.460
- Rx Rate (L1) (Bit/s)	100 M	100 M	100 M	100 M	100 M	100 M
- Rx Rate (Fps)	148.809	84.459	45.290	23.496	11.973	9.615
- Flood Count (Frames)	92	91	89	90	93	92
P-0-2-2						
- Tx (Frames)	4.464.284	2.533.780	1.358.692	704.884	359.192	288.460
- Tx Rate (L1) (Bit/s)	100 M	100 M	100 M	100 M	100 M	100 M
- Tx Rate (Fps)	148.809	84.459	45.290	23.496	11.973	9.615
- Rx (Frames)	4.464.284	2.533.780	1.358.692	704.884	359.192	288.460
- Rx Rate (L1) (Bit/s)	100 M	100 M	100 M	100 M	100 M	100 M
- Rx Rate (Fps)	148.809	84.459	45.290	23.496	11.973	9.615
- Flood Count (Frames)	90	93	91	90	90	90
P-0-2-3						
- Tx (Frames)	4.464.284	2.533.780	1.358.692	704.884	359.192	288.460
- Tx Rate (L1) (Bit/s)	100 M	100 M	100 M	100 M	100 M	100 M
- Tx Rate (Fps)	148.809	84.459	45.290	23.496	11.973	9.615
- Rx (Frames)	4.464.284	2.533.780	1.358.692	704.884	359.192	288.460
- Rx Rate (L1) (Bit/s)	100 M	100 M	100 M	100 M	100 M	100 M
- Rx Rate (Fps)	148.809	84.459	45.290	23.496	11.973	9.615
- Flood Count (Frames)	88	92	93	93	94	93
P-0-2-4					-	
- Tx (Frames)	4.464.284	2.533.780	1.358.692	704.884	359.192	288.460
- Tx Rate (L1) (Bit/s)	100 M	100 M	100 M	100 M	100 M	100 M
- Tx Rate (Fps)	148.809	84.459	45.290	23.496	11.973	9.615
- Rx (Frames)	4.464.284	2.533.780	1.358.692	704.884	359.192	288.460
- Rx Rate (L1) (Bit/s)	100 M	100 M	100 M	100 M	100 M	100 M
- Rx Rate (Fps)	148.809	84.459	45.290	23.496	11.973	9.615
- Flood Count (Frames)	89	91	88	90	94	86



P-0-2-5						
- Tx (Frames)	4.464.284	2.533.780	1.358.692	704.884	359.192	288.460
- Tx Rate (L1) (Bit/s)	100 M	100 M	100 M	100 M	100 M	100 M
- Tx Rate (Fps)	148.809	84.459	45.290	23.496	11.973	9.615
- Rx (Frames)	4.464.284	2.533.780	1.358.692	704.884	359.192	288.460
- Rx Rate (L1) (Bit/s)	100 M	100 M	100 M	100 M	100 M	100 M
- Rx Rate (Fps)	148.809	84.459	45.290	23.496	11.973	9.615
- Flood Count (Frames)	93	90	85	91	90	91

Frame Size	1518
Result State	PASS
Iter. #	1
Tx Rate (Percent)	10 %
Tx Rate (L1) (Bit/s)	499,99 M
Tx Rate (Fps)	40.637
Rx Rate (Percent)	10 %
Rx Rate (L1) (Bit/s)	499,99 M
Rx Rate (Fps)	40,64 K
Loss Rate (Percent)	0 %
Loss (Frames)	0
P-0-2-1	
- Tx (Frames)	243.820
- Tx Rate (L1) (Bit/s)	100 M
- Tx Rate (Fps)	8.127
- Rx (Frames)	243.820
- Rx Rate (L1) (Bit/s)	100 M
- Rx Rate (Fps)	8.127
- Flood Count (Frames)	87
P-0-2-2	01
- Tx (Frames)	243.820
- Tx Rate (L1) (Bit/s)	100 M
- Tx Rate (ET) (Blus)	8.127
- Rx (Frames)	243.820
- Rx Rate (L1) (Bit/s)	100 M
- Rx Rate (Fps)	8.127
- Flood Count (Frames)	88
P-0-2-3	00
- Tx (Frames)	243.820
- Tx Rate (L1) (Bit/s)	100 M 8.127
- Tx Rate (Fps)	
- Rx (Frames)	243.820
- Rx Rate (L1) (Bit/s)	100 M
- Rx Rate (Fps)	8.127
- Flood Count (Frames)	93
P-0-2-4	0.40.000
- Tx (Frames)	243.820
- Tx Rate (L1) (Bit/s)	100 M
- Tx Rate (Fps)	8.127
- Rx (Frames)	243.820
- Rx Rate (L1) (Bit/s)	100 M
- Rx Rate (Fps)	8.127
- Flood Count (Frames)	89
P-0-2-5	
- Tx (Frames)	243.820
- Tx Rate (L1) (Bit/s)	100 M
- Tx Rate (Fps)	8.127
- Rx (Frames)	243.820
- Rx Rate (L1) (Bit/s)	100 M
- Rx Rate (Fps)	8.127
- Flood Count (Frames)	95





Results for 20,00% Rate


Frame Size	64	128	256	512	1024	1280
Result State	PASS	PASS	PASS	PASS	PASS	PASS
Iter. #	1	1	1	1	1	1
Tx Rate (Percent)	20 %	20 %	20 %	20 %	20 %	20 %
Tx Rate (L1) (Bit/s)	1000 M	1000 M	1000 M	1000 M	1000 M	999,99 M
Tx Rate (Fps)	1.488.095	844.594	452.898	234.962	119.731	96.153
Rx Rate (Percent)	20 %	20 %	20 %	20 %	20 %	20 %
Rx Rate (L1) (Bit/s)	1000 M	1000 M	1000 M	1000 M	1000 M	999,99 M
Rx Rate (Fps)	1,49 M	844,59 K	452,9 K	234,96 K	119,73 K	96,15 K
Loss Rate (Percent)	0 %	0 %	0 %	0 %	0 %	0 %
Loss (Frames)	0	0	0	0	0	0
P-0-2-1						
- Tx (Frames)	8.928.568	5.067.564	2.717.388	1.409.772	718.388	576.920
- Tx Rate (L1) (Bit/s)	200 M	200 M	200 M	200 M	200 M	200 M
- Tx Rate (Fps)	297.619	168.919	90.580	46.992	23.946	19.231
- Rx (Frames)	8.928.568	5.067.564	2.717.388	1.409.772	718.388	576.920
- Rx Rate (L1) (Bit/s)	200 M	200 M	200 M	200 M	200 M	200 M
- Rx Rate (Fps)	297.619	168.919	90.580	46.992	23.946	19.231
- Flood Count (Frames)	89	92	92	92	91	93
P-0-2-2		-	-			
- Tx (Frames)	8.928.568	5.067.564	2.717.388	1.409.772	718.388	576.920
- Tx Rate (L1) (Bit/s)	200 M	200 M	200 M	200 M	200 M	200 M
- Tx Rate (Fps)	297.619	168.919	90.580	46.992	23.946	19.231
- Rx (Frames)	8.928.568	5.067.564	2.717.388	1.409.772	718.388	576.920
- Rx Rate (L1) (Bit/s)	200 M	200 M	200 M	200 M	200 M	200 M
- Rx Rate (Fps)	297.619	168.919	90.580	46.992	23.946	19.231
- Flood Count (Frames)	93	88	94	92	92	90
P-0-2-3						
- Tx (Frames)	8.928.568	5.067.564	2.717.388	1.409.772	718.388	576.920
- Tx Rate (L1) (Bit/s)	200 M	200 M	200 M	200 M	200 M	200 M
- Tx Rate (Fps)	297.619	168.919	90.580	46.992	23.946	19.231
- Rx (Frames)	8.928.568	5.067.564	2.717.388	1.409.772	718.388	576.920
- Rx Rate (L1) (Bit/s)	200 M	200 M	200 M	200 M	200 M	200 M
- Rx Rate (Fps)	297.619	168.919	90.580	46.992	23.946	19.231
- Flood Count (Frames)	90	94	91	92	90	89
P-0-2-4		0.	.			
- Tx (Frames)	8.928.568	5.067.564	2.717.388	1.409.772	718.388	576.920
- Tx Rate (L1) (Bit/s)	200 M	200 M	200 M	200 M	200 M	200 M
- Tx Rate (Fps)	297.619	168.919	90.580	46.992	23.946	19.231
- Rx (Frames)	8.928.568	5.067.564	2.717.388	1.409.772	718.388	576.920
- Rx Rate (L1) (Bit/s)	200 M	200 M	200 M	200 M	200 M	200 M
- Rx Rate (Fps)	297.619	168.919	90.580	46.992	23.946	19.231
- Flood Count (Frames)	95	89	92	94	88	94
P-0-2-5		00	J <u>L</u>	JT		34
- Tx (Frames)	8.928.568	5.067.564	2.717.388	1.409.772	718.388	576.920
1 A (1 1011103)	0.020.000	0.007.004	2.7 17.500	1.700.772	7 10.000	57 0.320



- Tx Rate (L1) (Bit/s)	200 M	200 M	200 M	200 M	200 M	200 M
- Tx Rate (Fps)	297.619	168.919	90.580	46.992	23.946	19.231
- Rx (Frames)	8.928.568	5.067.564	2.717.388	1.409.772	718.388	576.920
- Rx Rate (L1) (Bit/s)	200 M	200 M	200 M	200 M	200 M	200 M
- Rx Rate (Fps)	297.619	168.919	90.580	46.992	23.946	19.231
- Flood Count (Frames)	90	88	90	90	91	93

Frame Size	1518
Result State	PASS
Iter. #	1
Tx Rate (Percent)	20 %
Tx Rate (L1) (Bit/s)	1000 M
Tx Rate (Fps)	81.274
Rx Rate (Percent)	20 %
Rx Rate (L1) (Bit/s)	1000 M
Rx Rate (Fps)	81,27 K
Loss Rate (Percent)	0 %
Loss (Frames)	0
P-0-2-1	
- Tx (Frames)	487.644
- Tx Rate (L1) (Bit/s)	200 M
- Tx Rate (Fps)	16.255
- Rx (Frames)	487.644
- Rx Rate (L1) (Bit/s)	200 M
- Rx Rate (Fps)	16.255
- Flood Count (Frames)	92
P-0-2-2	
- Tx (Frames)	487.644
- Tx Rate (L1) (Bit/s)	200 M
- Tx Rate (Fps)	16.255
- Rx (Frames)	487.644
- Rx Rate (L1) (Bit/s)	200 M
- Rx Rate (Fps)	16.255
- Flood Count (Frames)	93
P-0-2-3	
- Tx (Frames)	487.644
- Tx Rate (L1) (Bit/s)	200 M
- Tx Rate (Fps)	16.255
- Rx (Frames)	487.644
- Rx Rate (L1) (Bit/s)	200 M
- Rx Rate (Fps)	16.255
- Flood Count (Frames)	92
P-0-2-4	
- Tx (Frames)	487.644
- Tx Rate (L1) (Bit/s)	200 M
- Tx Rate (Fps)	16.255
- Rx (Frames)	487.644
- Rx Rate (L1) (Bit/s)	200 M
- Rx Rate (Fps)	16.255
- Flood Count (Frames)	94
P-0-2-5	<u> </u>
- Tx (Frames)	487.644
- Tx Rate (L1) (Bit/s)	200 M
- Tx Rate (ET) (Blus)	16.255
- Rx (Frames)	487.644
- Rx Rate (L1) (Bit/s)	200 M
- Rx Rate (E1) (Bl/s)	16.255
- Flood Count (Frames)	91
- i lood Count (i lailles)	91





Results for 30,00% Rate


Frame Size	64	128	256	512	1024	1280
Result State	PASS	PASS	PASS	PASS	PASS	PASS
Iter. #	1	1	1	1	1	1
Tx Rate (Percent)	30 %	30 %	30 %	30 %	30 %	30 %
Tx Rate (L1) (Bit/s)	1,5 G	1,5 G	1,5 G	1,5 G	1,5 G	1,5 G
Tx Rate (Fps)	2.232.143	1.266.891	679.347	352.443	179.597	144.231
Rx Rate (Percent)	30 %	30 %	30 %	30 %	30 %	30 %
Rx Rate (L1) (Bit/s)	1,5 G	1,5 G	1,5 G	1,5 G	1,5 G	1,5 G
Rx Rate (Fps)	2,23 M	1,27 M	679,35 K	352,44 K	179,6 K	144,23 K
Loss Rate (Percent)	0 %	0 %	0 %	0 %	0 %	0 %
Loss (Frames)	0	0	0	0	0	0
P-0-2-1						
- Tx (Frames)	13.392.856	7.601.348	4.076.084	2.114.660	1.077.584	865.384
- Tx Rate (L1) (Bit/s)	300 M	300 M	300 M	300 M	300 M	300 M
- Tx Rate (Fps)	446.429	253.378	135.869	70.489	35.919	28.846
- Rx (Frames)	13.392.856	7.601.348	4.076.084	2.114.660	1.077.584	865.384
- Rx Rate (L1) (Bit/s)	300 M	300 M	300 M	300 M	300 M	300 M
- Rx Rate (Fps)	446.429	253.378	135.869	70.489	35.919	28.846
- Flood Count (Frames)	96	92	92	93	91	90
P-0-2-2						
- Tx (Frames)	13.392.856	7.601.348	4.076.084	2.114.660	1.077.584	865.384
- Tx Rate (L1) (Bit/s)	300 M	300 M	300 M	300 M	300 M	300 M
- Tx Rate (Fps)	446.429	253.378	135.869	70.489	35.919	28.846
- Rx (Frames)	13.392.856	7.601.348	4.076.084	2.114.660	1.077.584	865.384
- Rx Rate (L1) (Bit/s)	300 M	300 M	300 M	300 M	300 M	300 M
- Rx Rate (Fps)	446.429	253.378	135.869	70.489	35.919	28.846
- Flood Count (Frames)	94	92	93	95	93	92
P-0-2-3						
- Tx (Frames)	13.392.856	7.601.348	4.076.084	2.114.660	1.077.584	865.384
- Tx Rate (L1) (Bit/s)	300 M	300 M	300 M	300 M	300 M	300 M
- Tx Rate (Fps)	446.429	253.378	135.869	70.489	35.919	28.846
- Rx (Frames)	13.392.856	7.601.348	4.076.084	2.114.660	1.077.584	865.384
- Rx Rate (L1) (Bit/s)	300 M	300 M	300 M	300 M	300 M	300 M
- Rx Rate (Fps)	446.429	253.378	135.869	70.489	35.919	28.846
- Flood Count (Frames)	93	93	92	92	92	91
P-0-2-4						
- Tx (Frames)	13.392.856	7.601.348	4.076.084	2.114.660	1.077.584	865.384
- Tx Rate (L1) (Bit/s)	300 M	300 M	300 M	300 M	300 M	300 M
- Tx Rate (Fps)	446.429	253.378	135.869	70.489	35.919	28.846
- Rx (Frames)	13.392.856	7.601.348	4.076.084	2.114.660	1.077.584	865.384
- Rx Rate (L1) (Bit/s)	300 M	300 M	300 M	300 M	300 M	300 M
- Rx Rate (Fps)	446.429	253.378	135.869	70.489	35.919	28.846
- Flood Count (Frames)	91	92	92	92	90	94
P-0-2-5	<u> </u>					0.
- Tx (Frames)	13.392.856	7.601.348	4.076.084	2.114.660	1.077.584	865.384



- Tx Rate (L1) (Bit/s)	300 M	300 M	300 M	300 M	300 M	300 M
- Tx Rate (Fps)	446.429	253.378	135.869	70.489	35.919	28.846
- Rx (Frames)	13.392.856	7.601.348	4.076.084	2.114.660	1.077.584	865.384
- Rx Rate (L1) (Bit/s)	300 M	300 M	300 M	300 M	300 M	300 M
- Rx Rate (Fps)	446.429	253.378	135.869	70.489	35.919	28.846
- Flood Count (Frames)	93	94	91	90	92	93

F 0'	4540
Frame Size	1518
Result State	PASS
Iter. #	1
Tx Rate (Percent)	30 %
Tx Rate (L1) (Bit/s)	1,5 G
Tx Rate (Fps)	121.911
Rx Rate (Percent)	30 %
Rx Rate (L1) (Bit/s)	1,5 G
Rx Rate (Fps)	121,91 K
Loss Rate (Percent)	0 %
Loss (Frames)	0
P-0-2-1	
- Tx (Frames)	731.468
- Tx Rate (L1) (Bit/s)	300 M
- Tx Rate (Fps)	24.382
- Rx (Frames)	731.468
- Rx Rate (L1) (Bit/s)	300 M
- Rx Rate (Fps)	24.382
- Flood Count (Frames)	92
P-0-2-2	
- Tx (Frames)	731.468
- Tx Rate (L1) (Bit/s)	300 M
- Tx Rate (Fps)	24.382
- Rx (Frames)	731.468
- Rx Rate (L1) (Bit/s)	300 M
- Rx Rate (Fps)	24.382
- Flood Count (Frames)	92
P-0-2-3	
- Tx (Frames)	731.468
- Tx Rate (L1) (Bit/s)	300 M
- Tx Rate (Fps)	24.382
- Rx (Frames)	731.468
- Rx Rate (L1) (Bit/s)	300 M
- Rx Rate (Fps)	24.382
- Flood Count (Frames)	91
P-0-2-4	
- Tx (Frames)	731.468
- Tx Rate (L1) (Bit/s)	300 M
- Tx Rate (Fps)	24.382
- Rx (Frames)	731.468
- Rx Rate (L1) (Bit/s)	300 M
- Rx Rate (Fps)	24.382
- Flood Count (Frames)	90
P-0-2-5	
- Tx (Frames)	731.468
- Tx Rate (L1) (Bit/s)	300 M
- Tx Rate (Fps)	24.382
- Rx (Frames)	731.468
- Rx Rate (L1) (Bit/s)	300 M
- Rx Rate (Fps)	24.382
- Flood Count (Frames)	92
	<u> </u>





Results for 40,00% Rate


Frame Size	64	128	256	512	1024	1280
Result State	PASS	PASS	PASS	PASS	PASS	PASS
Iter. #	1	1	1	1	1	1
Tx Rate (Percent)	40 %	40 %	40 %	40 %	40 %	40 %
Tx Rate (L1) (Bit/s)	2 G	2 G	2 G	2 G	2 G	2 G
Tx Rate (Fps)	2.976.190	1.689.189	905.797	469.925	239.463	192.307
Rx Rate (Percent)	40 %	40 %	40 %	40 %	40 %	40 %
Rx Rate (L1) (Bit/s)	2 G	2 G	2 G	2 G	2 G	2 G
Rx Rate (Fps)	2,98 M	1,69 M	905,8 K	469,92 K	239,46 K	192,31 K
Loss Rate (Percent)	0 %	0 %	0 %	0 %	0 %	0 %
Loss (Frames)	0	0	0	0	0	0
P-0-2-1						
- Tx (Frames)	17.857.140	10.135.132	5.434.780	2.819.548	1.436.780	1.153.844
- Tx Rate (L1) (Bit/s)	400 M	400 M	400 M	400 M	400 M	400 M
- Tx Rate (Fps)	595.238	337.838	181.159	93.985	47.893	38.461
- Rx (Frames)	17.857.140	10.135.132	5.434.780	2.819.548	1.436.780	1.153.844
- Rx Rate (L1) (Bit/s)	400 M	400 M	400 M	400 M	400 M	400 M
- Rx Rate (Fps)	595.238	337.838	181.159	93.985	47.893	38.461
- Flood Count (Frames)	91	93	90	91	90	92
P-0-2-2						
- Tx (Frames)	17.857.140	10.135.132	5.434.780	2.819.548	1.436.780	1.153.844
- Tx Rate (L1) (Bit/s)	400 M	400 M	400 M	400 M	400 M	400 M
- Tx Rate (Fps)	595.238	337.838	181.159	93.985	47.893	38.461
- Rx (Frames)	17.857.140	10.135.132	5.434.780	2.819.548	1.436.780	1.153.844
- Rx Rate (L1) (Bit/s)	400 M	400 M	400 M	400 M	400 M	400 M
- Rx Rate (Fps)	595.238	337.838	181.159	93.985	47.893	38.461
- Flood Count (Frames)	90	96	93	91	91	90
P-0-2-3						
- Tx (Frames)	17.857.140	10.135.132	5.434.780	2.819.548	1.436.780	1.153.844
- Tx Rate (L1) (Bit/s)	400 M	400 M	400 M	400 M	400 M	400 M
- Tx Rate (Fps)	595.238	337.838	181.159	93.985	47.893	38.461
- Rx (Frames)	17.857.140	10.135.132	5.434.780	2.819.548	1.436.780	1.153.844
- Rx Rate (L1) (Bit/s)	400 M	400 M	400 M	400 M	400 M	400 M
- Rx Rate (Fps)	595.238	337.838	181.159	93.985	47.893	38.461
- Flood Count (Frames)	95	93	92	92	91	90
P-0-2-4						
- Tx (Frames)	17.857.140	10.135.132	5.434.780	2.819.548	1.436.780	1.153.844
- Tx Rate (L1) (Bit/s)	400 M	400 M	400 M	400 M	400 M	400 M
- Tx Rate (Fps)	595.238	337.838	181.159	93.985	47.893	38.461
- Rx (Frames)	17.857.140	10.135.132	5.434.780	2.819.548	1.436.780	1.153.844
- Rx Rate (L1) (Bit/s)	400 M	400 M	400 M	400 M	400 M	400 M
- Rx Rate (Fps)	595.238	337.838	181.159	93.985	47.893	38.461
- Flood Count (Frames)	95	92	90	91	90	94
P-0-2-5						
- Tx (Frames)	17.857.140	10.135.132	5.434.780	2.819.548	1.436.780	1.153.844



- Tx Rate (L1) (Bit/s)	400 M	400 M	400 M	400 M	400 M	400 M
- Tx Rate (Fps)	595.238	337.838	181.159	93.985	47.893	38.461
- Rx (Frames)	17.857.140	10.135.132	5.434.780	2.819.548	1.436.780	1.153.844
- Rx Rate (L1) (Bit/s)	400 M	400 M	400 M	400 M	400 M	400 M
- Rx Rate (Fps)	595.238	337.838	181.159	93.985	47.893	38.461
- Flood Count (Frames)	92	91	91	91	88	93

Frame Size	1518
Result State	PASS
Iter. #	1
Tx Rate (Percent)	40 %
Tx Rate (L1) (Bit/s)	2 G
Tx Rate (Fps)	162.549
Rx Rate (Percent)	40 %
Rx Rate (L1) (Bit/s)	2 G
Rx Rate (Fps)	162,55 K
Loss Rate (Percent)	0 %
Loss (Frames)	0
P-0-2-1	
- Tx (Frames)	975.292
- Tx Rate (L1) (Bit/s)	400 M
- Tx Rate (Fps)	32.510
- Rx (Frames)	975.292
- Rx Rate (L1) (Bit/s)	400 M
- Rx Rate (Fps)	32.510
- Flood Count (Frames)	92
P-0-2-2	
- Tx (Frames)	975.292
- Tx Rate (L1) (Bit/s)	400 M
- Tx Rate (Fps)	32.510
- Rx (Frames)	975.292
- Rx Rate (L1) (Bit/s)	400 M
- Rx Rate (Fps)	32.510
- Flood Count (Frames)	89
P-0-2-3	
- Tx (Frames)	975.292
- Tx Rate (L1) (Bit/s)	400 M
- Tx Rate (Fps)	32.510
- Rx (Frames)	975.292
- Rx Rate (L1) (Bit/s)	400 M
- Rx Rate (Fps)	32.510
- Flood Count (Frames)	92
P-0-2-4	-
- Tx (Frames)	975.292
- Tx Rate (L1) (Bit/s)	400 M
- Tx Rate (Fps)	32.510
- Rx (Frames)	975.292
- Rx Rate (L1) (Bit/s)	400 M
- Rx Rate (Fps)	32.510
- Flood Count (Frames)	93
P-0-2-5	30
- Tx (Frames)	975.292
- Tx Rate (L1) (Bit/s)	400 M
- Tx Rate (Fps)	32.510
- Rx (Frames)	975.292
- Rx Rate (L1) (Bit/s)	400 M
- Rx Rate (Fps)	32.510
- Flood Count (Frames)	90
1 lood Count (1 raines)	30





Results for 50,00% Rate


Frame Size	64	128	256	512	1024	1280
Result State	PASS	PASS	PASS	PASS	PASS	PASS
Iter. #	1	1	1	1	1	1
Tx Rate (Percent)	50 %	50 %	50 %	50 %	50 %	50 %
Tx Rate (L1) (Bit/s)	2,5 G	2,5 G	2,5 G	2,5 G	2,5 G	2,5 G
Tx Rate (Fps)	3.720.238	2.111.486	1.132.246	587.406	299.329	240.384
Rx Rate (Percent)	50 %	50 %	50 %	50 %	50 %	50 %
Rx Rate (L1) (Bit/s)	2,5 G	2,5 G	2,5 G	2,5 G	2,5 G	2,5 G
Rx Rate (Fps)	3,72 M	2,11 M	1,13 M	587,41 K	299,33 K	240,38 K
Loss Rate (Percent)	0 %	0 %	0 %	0 %	0 %	0 %
Loss (Frames)	0	0	0	0	0	0
P-0-2-1						
- Tx (Frames)	22.321.428	12.668.916	6.793.476	3.524.436	1.795.976	1.442.304
- Tx Rate (L1) (Bit/s)	500 M	500 M	500 M	500 M	500 M	500 M
- Tx Rate (Fps)	744.048	422.297	226.449	117.481	59.866	48.077
- Rx (Frames)	22.321.428	12.668.916	6.793.476	3.524.436	1.795.976	1.442.304
- Rx Rate (L1) (Bit/s)	500 M	500 M	500 M	500 M	500 M	500 M
- Rx Rate (Fps)	744.048	422.297	226.449	117.481	59.866	48.077
- Flood Count (Frames)	92	94	95	91	93	93
P-0-2-2						
- Tx (Frames)	22.321.428	12.668.916	6.793.476	3.524.436	1.795.976	1.442.304
- Tx Rate (L1) (Bit/s)	500 M	500 M	500 M	500 M	500 M	500 M
- Tx Rate (Fps)	744.048	422.297	226.449	117.481	59.866	48.077
- Rx (Frames)	22.321.428	12.668.916	6.793.476	3.524.436	1.795.976	1.442.304
- Rx Rate (L1) (Bit/s)	500 M	500 M	500 M	500 M	500 M	500 M
- Rx Rate (Fps)	744.048	422.297	226.449	117.481	59.866	48.077
- Flood Count (Frames)	93	93	92	90	88	92
P-0-2-3						
- Tx (Frames)	22.321.428	12.668.916	6.793.476	3.524.436	1.795.976	1.442.304
- Tx Rate (L1) (Bit/s)	500 M	500 M	500 M	500 M	500 M	500 M
- Tx Rate (Fps)	744.048	422.297	226.449	117.481	59.866	48.077
- Rx (Frames)	22.321.428	12.668.916	6.793.476	3.524.436	1.795.976	1.442.304
- Rx Rate (L1) (Bit/s)	500 M	500 M	500 M	500 M	500 M	500 M
- Rx Rate (Fps)	744.048	422.297	226.449	117.481	59.866	48.077
- Flood Count (Frames)	90	95	94	89	93	92
P-0-2-4						
- Tx (Frames)	22.321.428	12.668.916	6.793.476	3.524.436	1.795.976	1.442.304
- Tx Rate (L1) (Bit/s)	500 M	500 M	500 M	500 M	500 M	500 M
- Tx Rate (Fps)	744.048	422.297	226.449	117.481	59.866	48.077
- Rx (Frames)	22.321.428	12.668.916	6.793.476	3.524.436	1.795.976	1.442.304
- Rx Rate (L1) (Bit/s)	500 M	500 M	500 M	500 M	500 M	500 M
- Rx Rate (Fps)	744.048	422.297	226.449	117.481	59.866	48.077
- Flood Count (Frames)	92	90	94	90	91	93
P-0-2-5						
- Tx (Frames)	22.321.428	12.668.916	6.793.476	3.524.436	1.795.976	1.442.304



- Tx Rate (L1) (Bit/s)	500 M	500 M	500 M	500 M	500 M	500 M
- Tx Rate (Fps)	744.048	422.297	226.449	117.481	59.866	48.077
- Rx (Frames)	22.321.428	12.668.916	6.793.476	3.524.436	1.795.976	1.442.304
- Rx Rate (L1) (Bit/s)	500 M	500 M	500 M	500 M	500 M	500 M
- Rx Rate (Fps)	744.048	422.297	226.449	117.481	59.866	48.077
- Flood Count (Frames)	92	93	95	92	90	91

Frame Size	1518
Result State	PASS
Iter. #	1
Tx Rate (Percent)	50 %
Tx Rate (L1) (Bit/s)	2,5 G
Tx Rate (Fps)	203.185
Rx Rate (Percent)	50 %
Rx Rate (L1) (Bit/s)	2,5 G
Rx Rate (Fps)	203,19 K
Loss Rate (Percent)	0 %
Loss (Frames)	0
P-0-2-1	
- Tx (Frames)	1.219.112
- Tx Rate (L1) (Bit/s)	500 M
- Tx Rate (Fps)	40.637
- Rx (Frames)	1.219.112
- Rx Rate (L1) (Bit/s)	500 M
- Rx Rate (Fps)	40.637
- Flood Count (Frames)	92
P-0-2-2	
- Tx (Frames)	1.219.112
- Tx Rate (L1) (Bit/s)	500 M
- Tx Rate (Fps)	40.637
- Rx (Frames)	1.219.112
- Rx Rate (L1) (Bit/s)	500 M
- Rx Rate (Fps)	40.637
- Flood Count (Frames)	88
P-0-2-3	
- Tx (Frames)	1.219.112
- Tx Rate (L1) (Bit/s)	500 M
- Tx Rate (Fps)	40.637
- Rx (Frames)	1.219.112
- Rx Rate (L1) (Bit/s)	500 M
- Rx Rate (Fps)	40.637
- Flood Count (Frames)	90
P-0-2-4	
- Tx (Frames)	1.219.112
- Tx Rate (L1) (Bit/s)	500 M
- Tx Rate (Fps)	40.637
- Rx (Frames)	1.219.112
- Rx Rate (L1) (Bit/s)	500 M
- Rx Rate (Fps)	40.637
- Flood Count (Frames)	90
P-0-2-5	
- Tx (Frames)	1.219.112
- Tx Rate (L1) (Bit/s)	500 M
- Tx Rate (ET) (Blus)	40.637
- Rx (Frames)	1.219.112
- Rx Rate (L1) (Bit/s)	500 M
- Rx Rate (E1) (Blus)	40.637
- Flood Count (Frames)	90
rioda dount (i rames)	90





Results for 60,00% Rate


Frame Size	64	128	256	512	1024	1280
Result State	PASS	PASS	PASS	PASS	PASS	PASS
Iter. #	1	1	1	1	1	1
Tx Rate (Percent)	60 %	60 %	60 %	60 %	60 %	60 %
Tx Rate (L1) (Bit/s)	3 G	3 G	3 G	3 G	3 G	3 G
Tx Rate (Fps)	4.464.285	2.533.783	1.358.695	704.887	359.195	288.461
Rx Rate (Percent)	59,98 %	60 %	60 %	60 %	60 %	60 %
Rx Rate (L1) (Bit/s)	3 G	3 G	3 G	3 G	3 G	3 G
Rx Rate (Fps)	4,46 M	2,53 M	1,36 M	704,89 K	359,2 K	288,46 K
Loss Rate (Percent)	0,04 %	0 %	0 %	0 %	0 %	0 %
Loss (Frames)	50.340	0	0	0	0	0
P-0-2-1						
- Tx (Frames)	26.785.712	15.202.700	8.152.172	4.229.320	2.155.172	1.730.768
- Tx Rate (L1) (Bit/s)	600 M	600 M	600 M	600 M	600 M	600 M
- Tx Rate (Fps)	892.857	506.757	271.739	140.977	71.839	57.692
- Rx (Frames)	26.785.301	15.202.700	8.152.172	4.229.320	2.155.172	1.730.768
- Rx Rate (L1) (Bit/s)	599,99 M	600 M	600 M	600 M	600 M	600 M
- Rx Rate (Fps)	892.843	506.757	271.739	140.977	71.839	57.692
- Flood Count (Frames)	92	92	90	97	92	90
P-0-2-2						
- Tx (Frames)	26.785.712	15.202.700	8.152.172	4.229.320	2.155.172	1.730.768
- Tx Rate (L1) (Bit/s)	600 M	600 M	600 M	600 M	600 M	600 M
- Tx Rate (Fps)	892.857	506.757	271.739	140.977	71.839	57.692
- Rx (Frames)	26.761.942	15.202.700	8.152.172	4.229.320	2.155.172	1.730.768
- Rx Rate (L1) (Bit/s)	599,47 M	600 M	600 M	600 M	600 M	600 M
- Rx Rate (Fps)	892.065	506.757	271.739	140.977	71.839	57.692
- Flood Count (Frames)	88	89	95	92	89	94
P-0-2-3						
- Tx (Frames)	26.785.712	15.202.700	8.152.172	4.229.320	2.155.172	1.730.768
- Tx Rate (L1) (Bit/s)	600 M	600 M	600 M	600 M	600 M	600 M
- Tx Rate (Fps)	892.857	506.757	271.739	140.977	71.839	57.692
- Rx (Frames)	26.781.905	15.202.700	8.152.172	4.229.320	2.155.172	1.730.768
- Rx Rate (L1) (Bit/s)	599,91 M	600 M	600 M	600 M	600 M	600 M
- Rx Rate (Fps)	892.730	506.757	271.739	140.977	71.839	57.692
- Flood Count (Frames)	91	92	95	92	89	89
P-0-2-4						
- Tx (Frames)	26.785.712	15.202.700	8.152.172	4.229.320	2.155.172	1.730.768
- Tx Rate (L1) (Bit/s)	600 M	600 M	600 M	600 M	600 M	600 M
- Tx Rate (Fps)	892.857	506.757	271.739	140.977	71.839	57.692
- Rx (Frames)	26.775.293	15.202.700	8.152.172	4.229.320	2.155.172	1.730.768
- Rx Rate (L1) (Bit/s)	599,77 M	600 M	600 M	600 M	600 M	600 M
- Rx Rate (Fps)	892.510	506.757	271.739	140.977	71.839	57.692
- Flood Count (Frames)	91	92	93	93	93	91
P-0-2-5						
- Tx (Frames)	26.785.712	15.202.700	8.152.172	4.229.320	2.155.172	1.730.768



- Tx Rate (L1) (Bit/s)	600 M	600 M	600 M	600 M	600 M	600 M
- Tx Rate (Fps)	892.857	506.757	271.739	140.977	71.839	57.692
- Rx (Frames)	26.773.779	15.202.700	8.152.172	4.229.320	2.155.172	1.730.768
- Rx Rate (L1) (Bit/s)	599,73 M	600 M	600 M	600 M	600 M	600 M
- Rx Rate (Fps)	892.459	506.757	271.739	140.977	71.839	57.692
- Flood Count (Frames)	87	94	89	92	87	90

Frame Size	1518
Result State	PASS
Iter. #	1
Tx Rate (Percent)	60 %
Tx Rate (L1) (Bit/s)	3 G
Tx Rate (Fps)	243.823
Rx Rate (Percent)	60 %
Rx Rate (L1) (Bit/s)	3 G
Rx Rate (Fps)	243,82 K
Loss Rate (Percent)	0 %
Loss (Frames)	0
P-0-2-1	
- Tx (Frames)	1.462.936
- Tx Rate (L1) (Bit/s)	600 M
- Tx Rate (Fps)	48.765
- Rx (Frames)	1.462.936
- Rx Rate (L1) (Bit/s)	600 M
- Rx Rate (Fps)	48.765
- Flood Count (Frames)	91
P-0-2-2	31
- Tx (Frames)	1.462.936
- IX (Fidilles)	
- Tx Rate (L1) (Bit/s)	600 M
- Tx Rate (Fps)	48.765
- Rx (Frames)	1.462.936
- Rx Rate (L1) (Bit/s)	600 M
- Rx Rate (Fps)	48.765
- Flood Count (Frames)	88
P-0-2-3	
- Tx (Frames)	1.462.936
- Tx Rate (L1) (Bit/s)	600 M
- Tx Rate (Fps)	48.765
- Rx (Frames)	1.462.936
- Rx Rate (L1) (Bit/s)	600 M
- Rx Rate (Fps)	48.765
- Flood Count (Frames)	92
P-0-2-4	
- Tx (Frames)	1.462.936
- Tx Rate (L1) (Bit/s)	600 M
- Tx Rate (Fps)	48.765
- Rx (Frames)	1.462.936
- Rx Rate (L1) (Bit/s)	600 M
- Rx Rate (Fps)	48.765
- Flood Count (Frames)	96
P-0-2-5	
- Tx (Frames)	1.462.936
- Tx Rate (L1) (Bit/s)	600 M
- Tx Rate (Fps)	48.765
- Rx (Frames)	1.462.936
- Rx Rate (L1) (Bit/s)	600 M
- Rx Rate (Fps)	48.765
- Flood Count (Frames)	95
r lood Count (i raines)	33





Results for 70,00% Rate


Iter #	Frame Size	64	128	256	512	1024	1280
Tx Rate (L1) (Bit/s)	Result State	PASS	PASS	PASS	PASS	PASS	PASS
Tx Rate (L1) (Bit/s) 3,5 G 3,5 G 3,5 G 3,5 G 3,6 G 70% 30,5 G 3,5 G 3,6 G 3,5 G 3,5 G 3,5 G 3,5 G 3,5 G 3,6 G 3,5 G 3,5 G	Iter. #	1	1	1	1	1	1
Tx Rate (L1) (Bit/s)	Tx Rate (Percent)	70 %	70 %	70 %	70 %	70 %	70 %
Tx Rate (Fps)		3,5 G	3,5 G	3,5 G	3,5 G	3,5 G	3,5 G
Rx Rate (L1) (Bit/s) 1,86 M (2,77 K) 3,5 G (3,5 G) 3,5 G (3,5 G) 3,5 G (3,5 G) 3,5 G (3,5 G) 3,6 G (3,5 G) <th< td=""><td></td><td></td><td></td><td></td><td></td><td>419.061</td><td>336.538</td></th<>						419.061	336.538
Rx Rate (Fps)	Rx Rate (Percent)	0.04 %	70 %	70 %	70 %	70 %	70 %
Rx Rate (Fps)	Rx Rate (L1) (Bit/s)	1,86 M	3,5 G	3,5 G	3,5 G	3,5 G	3,5 G
Loss Rate (Percent) 99,95 % 0 % 0 % 0 % 0 % Loss (Frames) 156.166.761 0 0 0 0 P-0-2-1 0 0 0 0 0 -TX (Frames) 31.250.000 17.736.484 9.510.868 4.934.208 2.514.364 2.019.7 -TX Rate (Fps) 1.041.667 591.216 317.029 164.474 83.812 67.7 -Rx (Frames) 16.646 17.736.484 9.510.868 4.934.208 2.514.364 2.019.7 -Rx Rate (Fps) 372.87 K 700 M		2,77 K	2,96 M	1,59 M	822,37 K	419,06 K	336,54 K
P-0-2-1 - Tx (Frames) - 31.250.000 - Tx Rate (L1) (Bit/s) - Tx Rate (L1) (Bit/s) - Tx Rate (L1) (Bit/s) - Tx Rate (Fps) - 1.041.667 - Tx Rate (L1) (Bit/s) - Tx Rate (Fps) - Tx Rate (L1) (Bit/s) - Tx Rate (Fps) - Tx Rate (L1) (Bit/s) - Tx Rate (Fps)		99,95 %	0 %	0 %	0 %	0 %	0 %
- Tx (Frames)	Loss (Frames)	156.166.761	0	0	0	0	0
- Tx Rate (L1) (Bit/s)	P-0-2-1						
- Tx Rate (Fps)	- Tx (Frames)	31.250.000	17.736.484	9.510.868	4.934.208	2.514.364	2.019.228
- Tx Rate (Fps)	- Tx Rate (L1) (Bit/s)	700 M	700 M	700 M	700 M	700 M	700 M
-Rx (Frames)		1.041.667	591.216	317.029	164.474	83.812	67.308
- Rx Rate (Fps) 555 591.216 317.029 164.474 83.812 67 Flood Count (Frames) 91 91 93 89 88 - P-0-2-2 - Tx (Frames) 31.250.000 17.736.484 9.510.868 4.934.208 2.514.364 2.019 Tx Rate (L1) (Bit/s) 700 M 700			17.736.484	9.510.868	4.934.208	2.514.364	2.019.228
- Rx Rate (Fps) 555 591.216 317.029 164.474 83.812 67 Flood Count (Frames) 91 91 93 89 88 - P-0-2-2 - Tx (Frames) 31.250.000 17.736.484 9.510.868 4.934.208 2.514.364 2.019 Tx Rate (L1) (Bit/s) 700 M 700	- Rx Rate (L1) (Bit/s)	372,87 K	700 M	700 M	700 M	700 M	700 M
P-0-2-2 - Tx (Frames) 31.250.000 17.736.484 9.510.868 4.934.208 2.514.364 2.019 Tx Rate (L1) (Bit/s) 700 M 700			591.216	317.029	164.474	83.812	67.308
- Tx (Frames) 31.250.000 17.736.484 9.510.868 4.934.208 2.514.364 2.019 Tx Rate (L1) (Bit/s) 700 M				93	89	88	94
- Tx Rate (L1) (Bit/s)	, ,						-
- Tx Rate (L1) (Bit/s)	- Tx (Frames)	31.250.000	17.736.484	9.510.868	4.934.208	2.514.364	2.019.228
- Tx Rate (Fps)							700 M
- Rx (Frames)							67.308
- Rx Rate (L1) (Bit/s)	` ' '						2.019.228
- Rx Rate (Fps) 555 591.216 317.029 164.474 83.812 67.2 - Flood Count (Frames) 89 92 94 93 93 - 7x (Frames) 31.250.000 17.736.484 9.510.868 4.934.208 2.514.364 2.019.2 - Tx Rate (L1) (Bit/s) 700 M 7	, ,		700 M		700 M		700 M
- Flood Count (Frames) 89 92 94 93 93 93 P-0-2-3 - Tx (Frames) 31.250.000 17.736.484 9.510.868 4.934.208 2.514.364 2.019.3 - Tx Rate (L1) (Bit/s) 700 M 7							67.308
P-0-2-3 - Tx (Frames) - 31.250.000 - Tx Rate (L1) (Bit/s) - Tx Rate (L1) (Bit/s) - Tx Rate (Fps) - 1.041.667 - Tx Rate (Fps) - Rx (Frames) - Rx (Frames) - Rx (Frames) - Rx Rate (L1) (Bit/s) - Rx Rate (L2) (Bit/s) - Rx Rate (L3) (Bit/s) - Rx Rate (Fps) - Flood Count (Frames) - Tx Rate (L3) (Bit/s) - Tx Rate (L4) (Bit/s) - Tx Rate (L5) (Bit/s) - Tx Rate (Fps) - Tx Rate (94	93	93	94
- Tx Rate (L1) (Bit/s)	P-0-2-3						
- Tx Rate (L1) (Bit/s)	- Tx (Frames)	31.250.000	17.736.484	9.510.868	4.934.208	2.514.364	2.019.228
- Tx Rate (Fps)		700 M	700 M	700 M	700 M	700 M	700 M
- Rx (Frames) 16.649 17.736.484 9.510.868 4.934.208 2.514.364 2.019.3 - Rx Rate (L1) (Bit/s) 372,94 K 700 M 700 M 700 M 700 M 700 M 700 M - Rx Rate (Fps) 555 591.216 317.029 164.474 83.812 67.3 - Flood Count (Frames) 95 90 90 91 95 P-0-2-4 - Tx (Frames) 31.250.000 17.736.484 9.510.868 4.934.208 2.514.364 2.019.3 - Tx Rate (L1) (Bit/s) 700 M 700 M 700 M 700 M 700 M 700 M - Tx Rate (Fps) 1.041.667 591.216 317.029 164.474 83.812 67.3 - Rx (Frames) 16.649 17.736.484 9.510.868 4.934.208 2.514.364 2.019.3 - Rx Rate (L1) (Bit/s) 372,94 K 700 M 700 M 700 M 700 M 700 M 700 M - Rx Rate (Fps) 555 591.216 317.029 164.474 83.812 67.3 - Rx Rate (Fps) 95 95 93 91 P-0-2-5	- Tx Rate (Fps)						67.308
- Rx Rate (Fps) 555 591.216 317.029 164.474 83.812 67.3 - Flood Count (Frames) 95 90 90 91 95 P-0-2-4 - Tx (Frames) 31.250.000 17.736.484 9.510.868 4.934.208 2.514.364 2.019.3 - Tx Rate (L1) (Bit/s) 700 M 700		16.649		9.510.868	4.934.208	2.514.364	2.019.228
- Rx Rate (Fps) 555 591.216 317.029 164.474 83.812 67.3 - Flood Count (Frames) 95 90 90 91 95 P-0-2-4 - Tx (Frames) 31.250.000 17.736.484 9.510.868 4.934.208 2.514.364 2.019.3 - Tx Rate (L1) (Bit/s) 700 M 700	- Rx Rate (L1) (Bit/s)	372,94 K	700 M	700 M	700 M	700 M	700 M
- Flood Count (Frames) 95 90 90 91 95 P-0-2-4 - Tx (Frames) 31.250.000 17.736.484 9.510.868 4.934.208 2.514.364 2.019.3 - Tx Rate (L1) (Bit/s) 700 M	` ' ' '		591.216	317.029	164.474	83.812	67.308
- Tx (Frames) 31.250.000 17.736.484 9.510.868 4.934.208 2.514.364 2.019.3 - Tx Rate (L1) (Bit/s) 700 M 83.812 67.3 - Rx (Frames) 16.649 17.736.484 9.510.868 4.934.208 2.514.364 2.019.3 - Rx Rate (L1) (Bit/s) 372,94 K 700 M		95	90	90	91	95	93
- Tx Rate (L1) (Bit/s) 700 M 83.812 67.3 </td <td>P-0-2-4</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>	P-0-2-4						
- Tx Rate (L1) (Bit/s) 700 M 83.812 67.3 </td <td>- Tx (Frames)</td> <td>31.250.000</td> <td>17.736.484</td> <td>9.510.868</td> <td>4.934.208</td> <td>2.514.364</td> <td>2.019.228</td>	- Tx (Frames)	31.250.000	17.736.484	9.510.868	4.934.208	2.514.364	2.019.228
- Tx Rate (Fps) 1.041.667 591.216 317.029 164.474 83.812 67.3 - Rx (Frames) 16.649 17.736.484 9.510.868 4.934.208 2.514.364 2.019.3 - Rx Rate (L1) (Bit/s) 372,94 K 700 M 700 M <t< td=""><td>,</td><td>700 M</td><td>700 M</td><td>700 M</td><td>700 M</td><td>700 M</td><td>700 M</td></t<>	,	700 M	700 M	700 M	700 M	700 M	700 M
- Rx (Frames) 16.649 17.736.484 9.510.868 4.934.208 2.514.364 2.019.2 - Rx Rate (L1) (Bit/s) 372,94 K 700 M 700 M <td>, , , ,</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>67.308</td>	, , , ,						67.308
- Rx Rate (L1) (Bit/s) 372,94 K 700 M							2.019.228
- Rx Rate (Fps) 555 591.216 317.029 164.474 83.812 67.3 - Flood Count (Frames) 90 92 95 93 91 P-0-2-5 93 91	, ,						700 M
- Flood Count (Frames) 90 92 95 93 91 P-0-2-5	`						67.308
P-0-2-5	```						92
	, ,	30					
- IX (LIGHTS) 31,200,000 17,700,404 3.0 (0.00 4.504,200 2.014,004 7.019 (- Tx (Frames)	31.250.000	17.736.484	9.510.868	4.934.208	2.514.364	2.019.228



- Tx Rate (L1) (Bit/s)	700 M	700 M	700 M	700 M	700 M	700 M
- Tx Rate (Fps)	1.041.667	591.216	317.029	164.474	83.812	67.308
- Rx (Frames)	16.647	17.736.484	9.510.868	4.934.208	2.514.364	2.019.228
- Rx Rate (L1) (Bit/s)	372,89 K	700 M	700 M	700 M	700 M	700 M
- Rx Rate (Fps)	555	591.216	317.029	164.474	83.812	67.308
- Flood Count (Frames)	92	90	93	95	93	94

Frama Sina	4540
Frame Size	1518
Result State	PASS
Iter. #	1
Tx Rate (Percent)	70 %
Tx Rate (L1) (Bit/s)	3,5 G
Tx Rate (Fps)	284.460
Rx Rate (Percent)	70 %
Rx Rate (L1) (Bit/s)	3,5 G
Rx Rate (Fps)	284,46 K
Loss Rate (Percent)	0 %
Loss (Frames)	0
P-0-2-1	
- Tx (Frames)	1.706.760
- Tx Rate (L1) (Bit/s)	700 M
- Tx Rate (Fps)	56.892
- Rx (Frames)	1.706.760
- Rx Rate (L1) (Bit/s)	700 M
- Rx Rate (Fps)	56.892
- Flood Count (Frames)	89
P-0-2-2	09
- Tx (Frames)	1.706.760
	700 M
- Tx Rate (L1) (Bit/s)	
- Tx Rate (Fps)	56.892
- Rx (Frames)	1.706.760
- Rx Rate (L1) (Bit/s)	700 M
- Rx Rate (Fps)	56.892
- Flood Count (Frames)	93
P-0-2-3	
- Tx (Frames)	1.706.760
- Tx Rate (L1) (Bit/s)	700 M
- Tx Rate (Fps)	56.892
- Rx (Frames)	1.706.760
- Rx Rate (L1) (Bit/s)	700 M
- Rx Rate (Fps)	56.892
- Flood Count (Frames)	90
P-0-2-4	
- Tx (Frames)	1.706.760
- Tx Rate (L1) (Bit/s)	700 M
- Tx Rate (Fps)	56.892
- Rx (Frames)	1.706.760
- Rx Rate (L1) (Bit/s)	700 M
- Rx Rate (Fps)	56.892
- Flood Count (Frames)	92
P-0-2-5	32
	1 706 760
- Tx (Frames)	1.706.760
- Tx Rate (L1) (Bit/s)	700 M
- Tx Rate (Fps)	56.892
- Rx (Frames)	1.706.760
- Rx Rate (L1) (Bit/s)	700 M
- Rx Rate (Fps)	56.892
- Flood Count (Frames)	95





Results for 80,00% Rate


Frame Size	64	128	256	512	1024	1280
Result State	PASS	PASS	PASS	PASS	PASS	PASS
Iter. #	1	1	1	1	1	1
Tx Rate (Percent)	80 %	80 %	80 %	80 %	80 %	80 %
Tx Rate (L1) (Bit/s)	4 G	4 G	4 G	4 G	4 G	4 G
Tx Rate (Fps)	5.952.381	3.378.378	1.811.594	939.849	478.927	384.615
Rx Rate (Percent)	0,04 %	80 %	80 %	80 %	80 %	80 %
Rx Rate (L1) (Bit/s)	2,13 M	4 G	4 G	4 G	4 G	4 G
Rx Rate (Fps)	3,17 K	3,38 M	1,81 M	939,85 K	478,93 K	384,62 K
Loss Rate (Percent)	99,95 %	0 %	0 %	0 %	0 %	0 %
Loss (Frames)	178.476.295	0	0	0	0	0
P-0-2-1						
- Tx (Frames)	35.714.284	20.270.268	10.869.564	5.639.096	2.873.560	2.307.692
- Tx Rate (L1) (Bit/s)	800 M	800 M	800 M	800 M	800 M	800 M
- Tx Rate (Fps)	1.190.476	675.676	362.319	187.970	95.785	76.923
- Rx (Frames)	19.015	20.270.268	10.869.564	5.639.096	2.873.560	2.307.692
- Rx Rate (L1) (Bit/s)	425,94 K	800 M	800 M	800 M	800 M	800 M
- Rx Rate (Fps)	634	675.676	362.319	187.970	95.785	76.923
- Flood Count (Frames)	92	90	94	91	90	95
P-0-2-2						
- Tx (Frames)	35.714.284	20.270.268	10.869.564	5.639.096	2.873.560	2.307.692
- Tx Rate (L1) (Bit/s)	800 M	800 M	800 M	800 M	800 M	800 M
- Tx Rate (Fps)	1.190.476	675.676	362.319	187.970	95.785	76.923
- Rx (Frames)	19.020	20.270.268	10.869.564	5.639.096	2.873.560	2.307.692
- Rx Rate (L1) (Bit/s)	426,05 K	800 M	800 M	800 M	800 M	800 M
- Rx Rate (Fps)	634	675.676	362.319	187.970	95.785	76.923
- Flood Count (Frames)	96	94	90	91	93	91
P-0-2-3						
- Tx (Frames)	35.714.284	20.270.268	10.869.564	5.639.096	2.873.560	2.307.692
- Tx Rate (L1) (Bit/s)	800 M	800 M	800 M	800 M	800 M	800 M
- Tx Rate (Fps)	1.190.476	675.676	362.319	187.970	95.785	76.923
- Rx (Frames)	19.032	20.270.268	10.869.564	5.639.096	2.873.560	2.307.692
- Rx Rate (L1) (Bit/s)	426,32 K	800 M	800 M	800 M	800 M	800 M
- Rx Rate (Fps)	634	675.676	362.319	187.970	95.785	76.923
- Flood Count (Frames)	89	92	93	92	92	93
P-0-2-4						
- Tx (Frames)	35.714.284	20.270.268	10.869.564	5.639.096	2.873.560	2.307.692
- Tx Rate (L1) (Bit/s)	800 M	800 M	800 M	800 M	800 M	800 M
- Tx Rate (Fps)	1.190.476	675.676	362.319	187.970	95.785	76.923
- Rx (Frames)	19.032	20.270.268	10.869.564	5.639.096	2.873.560	2.307.692
- Rx Rate (L1) (Bit/s)	426,32 K	800 M	800 M	800 M	800 M	800 M
- Rx Rate (Fps)	634	675.676	362.319	187.970	95.785	76.923
- Flood Count (Frames)	92	91	92	93	93	93
P-0-2-5						
- Tx (Frames)	35.714.284	20.270.268	10.869.564	5.639.096	2.873.560	2.307.692



- Tx Rate (L1) (Bit/s)	800 M	800 M	800 M	800 M	800 M	800 M
- Tx Rate (Fps)	1.190.476	675.676	362.319	187.970	95.785	76.923
- Rx (Frames)	19.026	20.270.268	10.869.564	5.639.096	2.873.560	2.307.692
- Rx Rate (L1) (Bit/s)	426,18 K	800 M	800 M	800 M	800 M	800 M
- Rx Rate (Fps)	634	675.676	362.319	187.970	95.785	76.923
- Flood Count (Frames)	90	94	91	92	91	95

Frame Size	1518
Result State	PASS
Iter. #	1
Tx Rate (Percent)	80 %
Tx Rate (L1) (Bit/s)	4 G
Tx Rate (Fps)	325.097
Rx Rate (Percent)	80 %
Rx Rate (L1) (Bit/s)	4 G
Rx Rate (Fps)	325,1 K
Loss Rate (Percent)	0 %
Loss (Frames)	0
P-0-2-1	
- Tx (Frames)	1.950.584
- Tx Rate (L1) (Bit/s)	800 M
- Tx Rate (Fps)	65.019
- Rx (Frames)	1.950.584
- Rx Rate (L1) (Bit/s)	800 M
- Rx Rate (Fps)	65.019
- Flood Count (Frames)	92
P-0-2-2	
- Tx (Frames)	1.950.584
- Tx Rate (L1) (Bit/s)	800 M
- Tx Rate (Fps)	65.019
- Rx (Frames)	1.950.584
- Rx Rate (L1) (Bit/s)	800 M
- Rx Rate (Fps)	65.019
- Flood Count (Frames)	95
P-0-2-3	
- Tx (Frames)	1.950.584
- Tx Rate (L1) (Bit/s)	800 M
- Tx Rate (Fps)	65.019
- Rx (Frames)	1.950.584
- Rx Rate (L1) (Bit/s)	800 M
- Rx Rate (Fps)	65.019
- Flood Count (Frames)	91
P-0-2-4	
- Tx (Frames)	1.950.584
- Tx Rate (L1) (Bit/s)	800 M
- Tx Rate (Fps)	65.019
- Rx (Frames)	1.950.584
- Rx Rate (L1) (Bit/s)	800 M
- Rx Rate (Fps)	65.019
- Flood Count (Frames)	90
P-0-2-5	
- Tx (Frames)	1.950.584
- Tx Rate (L1) (Bit/s)	800 M
- Tx Rate (ET) (Blus)	65.019
- Rx (Frames)	1.950.584
- Rx Rate (L1) (Bit/s)	800 M
- Rx Rate (Fps)	65.019
- Flood Count (Frames)	90
- 1 lood Count (i railles)	90





Results for 90,00% Rate


Frame Size	64	128	256	512	1024	1280
Result State	PASS	PASS	PASS	PASS	PASS	PASS
Iter. #	1	1	1	1	1	1
Tx Rate (Percent)	90 %	90 %	90 %	90 %	90 %	90 %
Tx Rate (L1) (Bit/s)	4,5 G	4,5 G	4,5 G	4,5 G	4,5 G	4,5 G
Tx Rate (Fps)	6.696.428	3.800.675	2.038.043	1.057.331	538.793	432.692
Rx Rate (Percent)	0.03 %	90 %	90 %	90 %	90 %	90 %
Rx Rate (L1) (Bit/s)	1,39 M	4,5 G	4,5 G	4,5 G	4,5 G	4,5 G
Rx Rate (Fps)	2,07 K	3,8 M	2,04 M	1,06 M	538,79 K	432,69 K
Loss Rate (Percent)	99,97 %	0 %	0 %	0 %	0 %	0 %
Loss (Frames)	200.830.699	0	0	0	0	0
P-0-2-1						
- Tx (Frames)	40.178.568	22.804.052	12.228.260	6.343.984	3.232.756	2.596.152
- Tx Rate (L1) (Bit/s)	900 M	900 M	900 M	900 M	900 M	900 M
- Tx Rate (Fps)	1.339.286	760.135	407.609	211.466	107.759	86.538
- Rx (Frames)	11.136	22.804.052	12.228.260	6.343.984	3.232.756	2.596.152
- Rx Rate (L1) (Bit/s)	249,45 K	900 M	900 M	900 M	900 M	900 M
- Rx Rate (Fps)	371	760.135	407.609	211.466	107.759	86.538
- Flood Count (Frames)	89	92	91	93	93	91
P-0-2-2						
- Tx (Frames)	40.178.568	22.804.052	12.228.260	6.343.984	3.232.756	2.596.152
- Tx Rate (L1) (Bit/s)	900 M	900 M	900 M	900 M	900 M	900 M
- Tx Rate (Fps)	1.339.286	760.135	407.609	211.466	107.759	86.538
- Rx (Frames)	13.059	22.804.052	12.228.260	6.343.984	3.232.756	2.596.152
- Rx Rate (L1) (Bit/s)	292,52 K	900 M	900 M	900 M	900 M	900 M
- Rx Rate (Fps)	435	760.135	407.609	211.466	107.759	86.538
- Flood Count (Frames)	89	92	95	92	92	91
P-0-2-3						
- Tx (Frames)	40.178.568	22.804.052	12.228.260	6.343.984	3.232.756	2.596.152
- Tx Rate (L1) (Bit/s)	900 M	900 M	900 M	900 M	900 M	900 M
- Tx Rate (Fps)	1.339.286	760.135	407.609	211.466	107.759	86.538
- Rx (Frames)	13.060	22.804.052	12.228.260	6.343.984	3.232.756	2.596.152
- Rx Rate (L1) (Bit/s)	292,54 K	900 M	900 M	900 M	900 M	900 M
- Rx Rate (Fps)	435	760.135	407.609	211.466	107.759	86.538
- Flood Count (Frames)	93	92	94	92	91	90
P-0-2-4						
- Tx (Frames)	40.178.568	22.804.052	12.228.260	6.343.984	3.232.756	2.596.152
- Tx Rate (L1) (Bit/s)	900 M	900 M	900 M	900 M	900 M	900 M
- Tx Rate (Fps)	1.339.286	760.135	407.609	211.466	107.759	86.538
- Rx (Frames)	13.058	22.804.052	12.228.260	6.343.984	3.232.756	2.596.152
- Rx Rate (L1) (Bit/s)	292,5 K	900 M	900 M	900 M	900 M	900 M
- Rx Rate (Fps)	435	760.135	407.609	211.466	107.759	86.538
- Flood Count (Frames)	90	93	92	92	93	90
P-0-2-5						
- Tx (Frames)	40.178.568	22.804.052	12.228.260	6.343.984	3.232.756	2.596.152



- Tx Rate (L1) (Bit/s)	900 M	900 M	900 M	900 M	900 M	900 M
- Tx Rate (Fps)	1.339.286	760.135	407.609	211.466	107.759	86.538
- Rx (Frames)	11.828	22.804.052	12.228.260	6.343.984	3.232.756	2.596.152
- Rx Rate (L1) (Bit/s)	264,95 K	900 M	900 M	900 M	900 M	900 M
- Rx Rate (Fps)	394	760.135	407.609	211.466	107.759	86.538
- Flood Count (Frames)	88	93	90	91	92	90

Frame Size	4540
	1518
Result State	PASS
Iter. #	1
Tx Rate (Percent)	90 %
Tx Rate (L1) (Bit/s)	4,5 G
Tx Rate (Fps)	365.735
Rx Rate (Percent)	90 %
Rx Rate (L1) (Bit/s)	4,5 G
Rx Rate (Fps)	365,73 K
Loss Rate (Percent)	0 %
Loss (Frames)	0
P-0-2-1	
- Tx (Frames)	2.194.408
- Tx Rate (L1) (Bit/s)	900 M
- Tx Rate (Fps)	73.147
- Rx (Frames)	2.194.408
- Rx Rate (L1) (Bit/s)	900 M
- Rx Rate (Fps)	73.147
- Flood Count (Frames)	95
P-0-2-2	
- Tx (Frames)	2.194.408
- Tx Rate (L1) (Bit/s)	900 M
- Tx Rate (Fps)	73.147
- Rx (Frames)	2.194.408
- Rx Rate (L1) (Bit/s)	900 M
- Rx Rate (Fps)	73.147
- Flood Count (Frames)	73.147
P-0-2-3	00
- Tx (Frames)	0.404.400
	2.194.408
- Tx Rate (L1) (Bit/s)	900 M
- Tx Rate (Fps)	73.147
- Rx (Frames)	2.194.408
- Rx Rate (L1) (Bit/s)	900 M
- Rx Rate (Fps)	73.147
- Flood Count (Frames)	92
P-0-2-4	
- Tx (Frames)	2.194.408
- Tx Rate (L1) (Bit/s)	900 M
- Tx Rate (Fps)	73.147
- Rx (Frames)	2.194.408
- Rx Rate (L1) (Bit/s)	900 M
- Rx Rate (Fps)	73.147
- Flood Count (Frames)	92
P-0-2-5	
- Tx (Frames)	2.194.408
- Tx Rate (L1) (Bit/s)	900 M
- Tx Rate (Fps)	73.147
- Rx (Frames)	2.194.408
- Rx Rate (L1) (Bit/s)	900 M
- Rx Rate (Fps)	73.147
- Flood Count (Frames)	93
- Flood Count (Frames)	93





Results for 100,00% Rate

Frame Size	64	128	256	512	1024	1280
Result State	PASS	PASS	PASS	PASS	PASS	PASS
Iter. #	1	1	1	1	1	1
Tx Rate (Percent)	100 %	100 %	100 %	100 %	100 %	100 %
Tx Rate (L1) (Bit/s)	5 G	5 G	5 G	5 G	5 G	5 G
Tx Rate (Fps)	7.440.476	4.222.973	2.264.493	1.174.812	598.659	480.769
Rx Rate (Percent)	0.03 %	97,37 %	98,57 %	99,24 %	99,34 %	99,63 %
Rx Rate (L1) (Bit/s)	1,56 M	4,87 G	4,93 G	4,96 G	4,97 G	4,98 G
Rx Rate (Fps)	2,32 K	4,11 M	2,23 M	1,17 M	594,73 K	478,99 K
Loss Rate (Percent)	99,97 %	2,63 %	1,43 %	0,76 %	0,66 %	0,37 %
Loss (Frames)	223.144.804	3.332.564	970.018	266.871	117.757	53.327
P-0-2-1						
- Tx (Frames)	44.642.856	25.337.836	13.586.956	7.048.872	3.591.952	2.884.612
- Tx Rate (L1) (Bit/s)	1000 M	1000 M	1000 M	1000 M	1000 M	1000 M
- Tx Rate (Fps)	1.488.095	844.595	452.899	234.962	119.732	96.154
- Rx (Frames)	12.354	24.671.254	13.392.931	6.996.250	3.553.114	2.874.090
- Rx Rate (L1) (Bit/s)	276,73 K	973,69 M	985,72 M	992,53 M	989,19 M	996,35 M
- Rx Rate (Fps)	412	822.375	446.431	233.208	118.437	95.803
- Flood Count (Frames)	93	90	89	89	88	90
P-0-2-2						
- Tx (Frames)	44.642.856	25.337.836	13.586.956	7.048.872	3.591.952	2.884.612
- Tx Rate (L1) (Bit/s)	1000 M	1000 M	1000 M	1000 M	1000 M	1000 M
- Tx Rate (Fps)	1.488.095	844.595	452.899	234.962	119.732	96.154
- Rx (Frames)	14.621	24.671.360	13.392.963	6.996.278	3.578.265	2.873.038
- Rx Rate (L1) (Bit/s)	327,51 K	973,7 M	985,72 M	992,54 M	996,19 M	995,99 M
- Rx Rate (Fps)	487	822.379	446.432	233.209	119.276	95.768
- Flood Count (Frames)	91	95	90	92	80	89
P-0-2-3						
- Tx (Frames)	44.642.856	25.337.836	13.586.956	7.048.872	3.591.952	2.884.612
- Tx Rate (L1) (Bit/s)	1000 M	1000 M	1000 M	1000 M	1000 M	1000 M
- Tx Rate (Fps)	1.488.095	844.595	452.899	234.962	119.732	96.154
- Rx (Frames)	14.624	24.671.362	13.392.965	6.995.406	3.578.287	2.875.777
- Rx Rate (L1) (Bit/s)	327,58 K	973,7 M	985,72 M	992,41 M	996,2 M	996,94 M
- Rx Rate (Fps)	487	822.379	446.432	233.180	119.276	95.859
- Flood Count (Frames)	90	90	88	92	84	88
P-0-2-4						
- Tx (Frames)	44.642.856	25.337.836	13.586.956	7.048.872	3.591.952	2.884.612
- Tx Rate (L1) (Bit/s)	1000 M	1000 M	1000 M	1000 M	1000 M	1000 M
- Tx Rate (Fps)	1.488.095	844.595	452.899	234.962	119.732	96.154
- Rx (Frames)	14.622	24.671.359	13.392.965	6.993.729	3.563.540	2.871.020
- Rx Rate (L1) (Bit/s)	327,53 K	973,7 M	985,72 M	992,18 M	992,09 M	995,29 M
- Rx Rate (Fps)	487	822.379	446.432	233.124	118.785	95.701
- Flood Count (Frames)	90	90	90	91	89	83
P-0-2-5						
- Tx (Frames)	44.642.856	25.337.836	13.586.956	7.048.872	3.591.952	2.884.612



- Tx Rate (L1) (Bit/s)	1000 M	1000 M	1000 M	1000 M	1000 M	1000 M
- Tx Rate (Fps)	1.488.095	844.595	452.899	234.962	119.732	96.154
- Rx (Frames)	13.255	24.671.281	13.392.938	6.995.826	3.568.797	2.875.808
- Rx Rate (L1) (Bit/s)	296,91 K	973,69 M	985,72 M	992,47 M	993,55 M	996,95 M
- Rx Rate (Fps)	442	822.376	446.431	233.194	118.960	95.860
- Flood Count (Frames)	91	90	91	91	88	92

Frame Size	1518
Result State	PASS
Iter. #	1
Tx Rate (Percent)	100 %
Tx Rate (L1) (Bit/s)	5 G
Tx Rate (Fps)	406.371
Rx Rate (Percent)	98,69 %
Rx Rate (L1) (Bit/s)	4,93 G
Rx Rate (Fps)	401,05 K
Loss Rate (Percent)	1,31 %
Loss (Frames)	159.758
P-0-2-1	
- Tx (Frames)	2.438.228
- Tx Rate (L1) (Bit/s)	1000 M
- Tx Rate (Fps)	81.274
- Rx (Frames)	2.431.956
- Rx Rate (L1) (Bit/s)	997,43 M
- Rx Rate (Fps)	81.065
- Flood Count (Frames)	82
P-0-2-2	
- Tx (Frames)	2.438.228
- Tx Rate (L1) (Bit/s)	1000 M
- Tx Rate (Fps)	81.274
- Rx (Frames)	2.389.024
- Rx Rate (L1) (Bit/s)	979,82 M
- Rx Rate (Fps)	79.634
- Flood Count (Frames)	87
P-0-2-3	
- Tx (Frames)	2.438.228
- Tx Rate (L1) (Bit/s)	1000 M
- Tx Rate (Fps)	81.274
- Rx (Frames)	2.385.413
- Rx Rate (L1) (Bit/s)	978,34 M
- Rx Rate (Fps)	79.514
- Flood Count (Frames)	90
P-0-2-4	
- Tx (Frames)	2.438.228
- Tx Rate (L1) (Bit/s)	1000 M
- Tx Rate (Fps)	81.274
- Rx (Frames)	2.431.908
- Rx Rate (L1) (Bit/s)	997,41 M
- Rx Rate (Fps)	81.064
- Flood Count (Frames)	84
P-0-2-5	
- Tx (Frames)	2.438.228
- Tx Rate (L1) (Bit/s)	1000 M
- Tx Rate (Fps)	81.274
- Rx (Frames)	2.393.081
- Rx Rate (L1) (Bit/s)	981,48 M
- Rx Rate (Fps)	79.769
- Flood Count (Frames)	89
1 7000 Count (1 fames)	09



